

Windows XP (and similarly, 2000): Setting Up a Network Printer

PREPARATION


In order to install a network printer, you must know the printer's **Manufacturer**, **Model Name**, and **IP Address**:

* The **Manufacturer** and **Model Name** can be found on the printer case; an example is HP LaserJet 4000N.


* The **IP Address** can be found on a label attached to the printer; an example is 10.10.2.1

SETUP

1. Click on the **Start** button, then *click* **Control Panel**, then *click* **Printers and Faxes**, then *click* **Add Printer**.




2. A new Add Printer Wizard window opens. Click **Next** to start.



3. **Select Local printer attached to this computer.** Ensure **Automatically detect and install my Plug and Play printer** is **NOT** checked.


4. **Click Next** to continue.




5. **Select Create a new port.**

6. Beside **Type of Port**, **click** on the **down arrow**, then **click** on **Standard TCP/IP Port**.

7. **Click Next** to continue.




8. A new Add Printer Port Wizard will open. **Click Next** to continue.



9. Enter the printer's **IP Address** in the **Printer Name or IP Address** field.


10. The **Port Name** will automatically be filled when you enter the **IP Address**. Do not change the **Port Name**.

Click **Next** to continue.



IF YOU HAVE PROBLEMS – for example, “The device could not be identified”. This message means that the IP Address for the printer is NOT available on the network. *Select* the **Back** button and make sure you entered the correct IP Address. Check to see that your network printer is powered on and displays a 'ready' status.

11. *Windows XP* will scan the network to find the printer's IP Address. This may take a minute. *Select* **Finish** to continue.



12. *Windows XP* will select the detected printer Manufacturer and Model Number. You may have to change this selection.

NOTE: If the printer is listed but there is more than one Model Number to choose from, please select the model PCL HP and PS for Tektronix printers.




13. IF the network printer is NOT detected, *select Have Disk* and *Browse* to ALFS// AL Resources/ Software/ Windows Software/ Printer Drivers/. Go to the corresponding printer folder to find the correct .inf file, OR to a disk.

NOTE: You can *select* the **Windows Update** button to look for the proper software drivers on the Microsoft website, although it may not find them.


14. Confirm the selected printer driver, then click *Next* to continue.

15. Assign the printer a **Name**. Use the default name, or enter another name.

16. *Select Yes* if you want to use the printer as the default printer. *Click Next* to continue.




17. Select Do not share the network printer, then click **Next** to continue.



18. Select **Yes** to print a test page, then click **Next** to continue.

19. Check the network printer to ensure the test page printed. Select **Yes** when prompted to confirm a successful test page, then click Next to continue.

20. Click on the **Finish** button to complete the Add Printer Wizard.



Congratulations! If the test page printed, the network printer is successfully installed. Set Properties for duplexing and additional paper trays.